



Items List

Before using this product, please check whether the contents of the package are complete.

① X3 (White+Red light) × 1 ② Type-C charging cable Lanyard × 1 ③ User manual, Warranty card × 1

Standard version(seat charger) Advanced version(power storage box)

④ Charging box (power storage box / seat charger) × 1

- 01 -

Product Operation

Portable lamp

Seat charger (Standard version)

- 02 -

Power storage box (Advanced version)

Installation method

Disassemble and assemble the Type-C charging cord hand rope

- 03 -

Data cable Android plug conversion Apple plug method.

Put the flashlight into the power storage box in the correct direction.

- 04 -

Operation Method

White light OFF ON Red light OFF ON Indicator Light OFF ON

① Hold ② Hold ③ Hold ④ Hold ⑤ Hold

- 05 -

Product Warranty

製品保証カード / 产品保修凭证

Name / 姓名 / 客户姓名 _____
Telephone / 電話番号 / 联系电话 _____
Address / 住所 / 联系地址 _____

Model number / 製品番号 / 产品型号 **X3**
Product series number / 製品コード / 产品编码 _____
Name of store / 販売店 / 购买商店 _____
Date of purchase / 購入日 / 购买日期 _____

Get your e-warranty card and e-manual by visiting the following URL or scanning the QR code.
<https://www.wubenlight.com/pages/product-registration>

- 01 -

Charge/Discharge

Seat charger (Standard version)

Power storage box (Advanced version)

- 06 -

Discharge 01

Discharge 02

- 07 -

Functional parameters

SAMSUNG LH351D						
Fl1 standard	Turbo	High	Med	Low	Strobe	SOS
700~200 lumens	150 lumens	50 lumens	1 lumen	700 lumens	150 lumens	
30s + 1.5 hours	2 hours	6 hours	50 hours	/	/	

LUMINUS SST10		
Fl1 standard	High	Low
80~30 lumens	1 lumen	30 lumens
30s + 2 hours	30 hours	30 hours

102 m 2590 Candelas 1.0 m IP65

Portable lamp: 70g | 2.47oz.
Portable lamp: 70 mm × 35 mm × 21 mm | 2.76 in × 1.38 in × 0.83 in

- 08 -

(EN) English

Warnings

- Please read the instructions carefully before use.
- This product will generate heat during use, so please pay attention to protect it so as not to cause harm to human body.
- This product is a bright product, please do not irradiate human eyes to avoid injury.
- Please keep this product out of the reach of children under 12.
- Please do not disassemble and repair the torch yourself, as the product will not be guaranteed after disassembly.
- Do not throw the product into the fire.
- This product is a non-diving product. Please do not use it underwater for a long time.

Operation Method

Reminder: The product is set to be locked by default when it leaves the factory. After receiving the product, please click four times to complete the first unlock!

White light

ON/OFF: Click the switch to turn on the flashlight, and then click the button to turn off the flashlight. The flashlight has a brightness memory function, however it will not memorize the flashing mode and the Turbo mode.

Default Output Selections: When the flashlight is on, press and hold the switch to cycle the brightness of the flashlight: Low-Med-High-Low Cycle. Release the switch in any gear to lock the brightness/Red lantern.

Instant Turbo: When Red light is off, double-click the switch to enter the Turbo mode. Double click again to return to previous mode.

SOS- flash: When Red light is off, hit the switch three times to enter the flash mode, and hit it three times again to circularly switch the flash mode.

- 09 -

Lock/Unlock

In the power-off state, press the switch four times, display lock icon, indicating the flashlight lock. Press the button four more times, and the low light will light up, indicating that the lock is released.

Red light

ON/OFF: When the flashlight is off, press and hold the switch to turn on the flashlight, and then click the button to turn off the flashlight.

Default Output Selections

When the flashlight is on, press and hold the switch to cycle the brightness of the flashlight: Low-High-Low Cycle. Release the switch in any gear to lock the brightness.

Indicator Light

Under any circumstance, you can activate the blue indicator light by clicking the button five times consecutively. The blue indicator light consumes a lot of power. If it is not necessary, it is recommended to turn it off to avoid impacting light/battery life of the main light.

Indicator Light	ON
Charge	Breathing lamp
Fully charged	Lights out

Display screen display

Discharge	Gear position, electric quantity
Charge	The ticker flashes when charging and stops when fully charged

- 10 -

Maintenance Method

- Please use a WUBEN battery or WUBEN-recommended batteries.
- When the product indicates low power, please charge or replace the battery in time to prevent any adverse effects on the battery's lifespan.
- Please store the product in a dry and ventilated place.

Solutions to Common Problems

Problem	Causes	Solution
Abnormal flash or failure to turn on	Check whether the flashlight is locked. Check whether the switch is turned on correctly. Check whether the battery is charged.	Unlock flashlight. Turn on the switch. Check the battery with a charger.
Abnormal Sound	Check whether there are foreign objects falling in. Part damage	Pour out foreign matter. Please contact your local dealer

Warranty Policy

15-day replacement: Within 15 days from the date of purchase, if the product has any quality problems, you can request a free replacement.

1 year warranty: Within 1 year from the date of purchase, WUBEN offers free repairs for the product (excluding accessories) in case of quality issues. This warranty is applicable to WUBEN registered customers.

- 11 -

Battery warranty

WUBEN offers a 1-year warranty for the rechargeable batteries, but other included accessories are not covered by the warranty.

Lifetime maintenance: From the date of purchase, if the product encounters any issues after the initial 1-year period, WUBEN will offer paid repair for WUBEN-registered customers.

No Warranty Scope

- Man-made destruction causes product damage.
- Falling to operate according to the instructions and causing damage.
- The battery is damaged due to improper use and leakage.
- Unusually worn.
- Damage caused by force majeure.
- Gifts.

SHENZHEN SHENGQI LIGHTING TECHNOLOGY CO., LTD.
Add: Floor 5, Building A, Zhenhan Industrial Park, No. 1 Zhenhan Road, Jihua Street, Longgang District, Shenzhen, Guangdong, China
E-mail: support@wubenlight.com
Web: www.wubenlight.com

- 12 -

(CN) 简体中文

警告说明

- 使用前, 请认真阅读说明书。
- 本品在使用过程中会产生热量, 请注意保护, 以免对人体造成伤害。
- 本品为高原产品, 请勿对人眼直射, 以免造成伤害。
- 请将本品放到12岁以下儿童接触不到的地方。
- 本品为内置不可拆卸电池, 请勿私自拆卸与维修产品, 私自拆卸后不予保修产品。
- 请勿将产品投入火中。
- 本品为非潜水类产品, 请勿长时间在水下使用。

操作方法

出厂默认锁定, 收到产品后请点击四次解锁!

白灯

- 开机/关机: 单击按键可点亮白灯, 再次单击关闭。具有照明亮度记忆功能, 不会记忆闪烁模式和呼吸模式。
- 档位调节: 开机状态, 长按按键可以循环切换亮度: 低-中-高-低循环。在任何档位下松开开关, 即可锁定亮度。
- 快速模式: 红灯关闭状态, 双击按键进入红光, 再次双击退回进入新模式。
- 闪烁模式: 红灯关闭状态, 三击按键进入呼吸模式, 再次三击可循环切换闪烁模式: 爆闪-SOS-爆闪, 表示锁定解除。
- 锁定/解锁手电筒: 关机状态, 四击按键, 显示锁定图标, 表示手电筒锁定; 再次四击按键, 低电量点亮, 表示锁定解除。

红灯

- 开机/关机: 关机状态下, 长按按键可点亮红灯, 单击关闭。
- 档位调节: 开机状态, 长按按键可以循环切换亮度: 低-高-低循环。在任何档位下松开开关, 即可锁定亮度。

- 13 -

指示灯

任何状态下, 五击按键可以打开蓝色指示灯功能, 再次五击可以关闭蓝色指示灯功能。蓝色指示灯额定寿命大, 如充电量建议关闭以免影响主灯的使用寿命。

主灯亮	常亮
充电	呼吸灯
充满电	灯灭

显示屏显示

放电	档位、电量
充电	充电时电量进度条, 满电时停止

保养方法

- 请使用原装的电池或本品牌再的电池。
- 非电指示电量不足时, 请及时充电或更换电池, 以免影响产品正常使用。
- 请将手电筒置于通风干燥处存放。

常见问题处理方法

问题描述	原因	解决方法
灯内或不亮	检查手电筒是否锁定 检查开关是否正确打开	解锁手电筒 打开开关
闪烁	检查电池是否有人	用充电器检测电池
异响	检查是否有异物掉入 零件损伤	倒出异物 请联系当地经销商

- 14 -

保修规则

1. 保修范围

- 15天包换: 自购买之日起, 15天内如产品出现质量问题, 可选择更换同型号产品。
- 1年保修: 自购买之日起, 在官方售后网站注册登记产品的用户, 1年内如出现质量问题, 秀本将提供免费维修服务。
- 电池保修: 充电电池保修期为1年, 产品附加配件不在保修范围内。
- 终身维修: 自购买之日起, 注册用户1年后如出现质量问题, 秀本将提供免费维修服务。
- 如无争议, 双方协商处理。

2. 不予保修范围

- 人为破坏造成产品损坏的。
- 不按说明书操作使用造成损坏的。
- 电池使用不当, 电池漏液造成损坏的。
- 非正常使用造成的。
- 不可抗力因素造成损坏的。
- 赠品。

最终解释权归秀本品牌所有。

CE 本产品符合2015/863/EU修订版EMC, 2014/30/EU指令RoHS 2011/65/EU指令。本产品只能作为电子电气类废弃物处理。

地址: 深圳市宝安区福海街道新桥社区新桥工业园A栋5楼
地址: 广东省深圳市宝安区西乡街道铁岗社区铁岗工业区A栋5楼
网址: www.wubenlight.com
邮箱: support@wubenlight.com 电话: +86-755-21010616
生产厂家: 东莞市盈光照明科技有限公司
广东生产厂家: 广东省东莞市石碣镇石碣大道11号
执行标准: Q/4419005Q24 销售电话: 0769-86661133 秀本官方网站 订购号

- 15 -

(JP) 日本語

安全上の注意

- 本製品は使用中に熱が発生し、本体及びヘッド部が高温になる場合がございます。使用上問題はありますが、本製品のヘッド部ができるだけ接触しない様注意してください。
- 本製品は連続点灯すると熱を持つ場合がございますが、発火や爆発の危険はありませんので安心して使用ください。
- 光を直接目に当てないでください。
- 子供の手の届かないところに保管してください。
- 本製品を修理、改造しないでください。自分で修理、改造した製品は修理保証に適用しません。
- 火を入れるなどしないでください。
- 本製品は「ダイバー用」仕様になっておりませんので、長時間水中で使用しないでください。
- ※付属の「ACアダプター」は本製品及び充電ケーブルが正常に動作するための製品保証などの危険を避けるため、他の物に触れたり近づいたりしないでください。

内容物の名称

本体及び付属品一式が同梱されているか確認してください。

- 本体 X3 × 1
- Type-C 充電ケーブル-一体型ストラップ × 1
- 充電ボックス (アドバンスバージョン) × 1
- またはシートチャージャー (スタンダードバージョン) × 1
- 取扱説明書 × 1

※充電ボックスタイプ (アドバンスバージョン) とシートチャージャータイプ (スタンダードバージョン) の2種類があります。

- 24 -

各部名称

ライト本体 充電ボックス (アドバンスバージョン) シートチャージャー (スタンダードバージョン)

- 25 -

取外し方法 (充電ケーブルを使用する時)

充電ケーブル一体型ストラップ

- 26 -

Lightingケーブルへの接続方法

① 充電ケーブル ② 充電ストラップパーツ

本体を正しい向きで充電ボックスに入れる

- 27 -

シートチャージャーに装着する

ご利用方法

① 点灯: 工場出荷時はスイッチロック状態です。ご利用の前に、スイッチボタンを素早く連続4回 (約2秒以内) 押し、スイッチロックを解除してください。

白色光

- 点灯・消灯: スイッチボタンを押すとON-OFF-ONと切り替わります。モード記憶機能搭載。フラッシュモードとTurboモードは記憶しません。
- モード切替: 点灯時、スイッチボタンを長押しするとLow-Med-Highと切り替わります。指を離すとモードが固定されます。
- クイックTurboモード: 赤色光が点灯時、スイッチボタンを素早く連続2回押し→Turboモードで点灯→素早く連続3回押し→元のモードで点灯。
- フラッシュモード: 赤色光が点灯時、スイッチボタンを素早く連続3回押し→Strobeモードで点灯→素早く連続3回押し→SOSモードで点灯→素早く連続3回押し→Strobeモードで点灯と切り替わります。

- 28 -

スイッチロック機能

消灯時、スイッチボタンを素早く連続4回押し(約2秒以内)→ロックアイコン デジタルモニターに表示→スイッチロック状態。スイッチボタンを素早く連続4回押し→Lowモードで点灯しロック解除。

赤色光

- 点灯・消灯: スイッチボタンを長押しすると点灯。再度スイッチボタンを押すと消灯します。
- モード切替: 点灯時、スイッチボタンを長押しするとLow→High→Lowと切り替わります。指を離すとモードが固定されます。

青色補助ライト設定

点灯時、スイッチボタンを素早く5回連続で押す→青色補助ライトが点灯。青色補助ライトは、多くの電力を消費する為、必要な場合は、消灯することをお勧めします。点灯時及び消灯時、スイッチボタンを素早く5回連続で押す→青色補助ライトが消灯。※ホワイトのみ、本体が緑色に白変します。

- 29 -

充電方法/給電方法

※ワイヤレス充電器 約2時間で満充電
シートチャージャー (スタンダードバージョン)

充電

充電ボックス (アドバンスバージョン)

- 30 -

充電中の表示

1. ボタンを押してください

2.5 秒間点灯表示 青色点灯: 電池残量多い 赤色点灯: 電池残量少ない

3. 約2時間30分で充電完了 ※満充電時、デジタルモニターは非表示となります。

給電

- 31 -

仕様

SAMSUNG LH351D						
モード	Turbo	High	Med	Low	Strobe	SOS
700~200 lumens	150 lumens	50 lumens	1 lumen	700 lumens	150 lumens	
30分+1.5時間	2時間	6時間	50時間	/	/	

LUMINUS SST10		
モード	High	Low
80~30 lumens	1 lumen	30 lumens
30分+2時間	30時間	30時間

102 m 2590 カンデラ 1.0 m IP65

X3本体: 65g(電池含む) 充電ボックス: 125g シートチャージャー: 12g
70 mm × 35 mm × 21 mm (L × W × H)

- 32 -

メンテナンス方法

- 本製品の残量不足の表示が出た場合、充電してください。
- 本製品は換気の良い乾燥した場所に保管してください。

故障かなと思ったら

現象	原因	対処方法
フラッシュまたは点灯しない	スイッチが正しく押されていないか確認してください スイッチがロックされていないか確認する	スイッチの確認 ロック解除
異常音	パナチリ-障害を確認してください 部品の損傷	充電してください 販売店にご連絡ください

国内保証規定

- お買い上げ日から15日以内で、商品に不具合がある場合、お買い上げ店にて無料交換を申請することができます。
- 購入した日から1年以内に商品に不具合が発生した場合、無償修理、または同一品、同等品と無償交換いたします。
- 取扱説明書に従った正常な使用状態で故障した場合は、保証期間内に限り規定に基づき無料で修理交換いたします。

- 33 -

- 保証期間内でも次の場合は有償修理もしくは保証対象外となります。
- 誤用・乱用及び取扱い不注意による故障。
- 火災・地震・水害などの災害による故障。
- 分解や不当な修理、改造及び異常電圧に起因する故障。
- 使用中に発生した火、煙などの外観上の変化。
- 経年変化による変色や素材の劣化。
- 登録いただいたシリアル番号と製品本体のシリアル番号が一致しない場合。
- 付属品のリチウムイオン充電器を含む本製品の保証対象外となります。
- WUBENからの取り扱った修理品。
- 最終的な診断する権利はWUBENにあります。
- 修理期間中の代替機のご用意はございません。
- 保証期間中に何らかの理由により修理及び交換ができない場合は、同等品との交換により対応させていただきます。
- 本保証の適用範囲は本製品のみならず、本製品の使用または使用不能から生じた直接的または間接的損害に対し、弊社は一切の責任を負いません。
- 本保証は日本国内においてのみ有効です。

※海外ショップでご購入された場合は、保証及びサポート対象外となります。

製造元: DONGGUAN CITY SHENGQI LIGHTING TECHNOLOGY CO., LTD.
販売元: WUBEN株式会社
住所: 廣東省佛山市南海区 1 丁目 7 39 号 イズムスクエア D 号
TEL: 084-999-4700 FAX: 084-999-4701
Mail: info@wuben.co.jp URL: http://www.wuben.co.jp

- 34 -